

Fibroids - Post-UAE

- Subtractions: axial post – axial pre-contrast

1. SCOUT

2. SAGITTAL T2 FSE

3. SAGITTAL T2 BLADE

Decide FSE vs. BLADE for remainder of T2WI, MD check if need help

4. AXIAL T2 – FSE or BLADE

5. AXIAL DIFFUSION – b values of 50, 400 and 800

6. CORONAL OBLIQUE T2 – along the long & short axis of the uterus, FSE or BLADE

7. AXIAL T1

8. AXIAL VIBE

Inject contrast

9. AXIAL VIBE – subtraction

10. SAGITTAL VIBE

11. CORONAL VIBE