

a radiology partners practice

Fibroids - Pre-UAE

- 1. SCOUT
- 2. SAGITTAL T2 FSE
- 3. SAGITTAL T2 BLADE

Decide FSE vs. BLADE for remainder of T2WI, MD check if need help

- 4. AXIAL T2 FSE or BLADE
- 5. AXIAL DIFFUSION b values of 50, 400 and 800
- 6. CORONAL OBLIQUE T2 along the long & short axis of the uterus, FSE or BLADE
- 7. AXIAL T1
- 8. AXIAL VIBE

Inject contrast

- 9. PELVIC MRA & MRV (1st and 2nd pass)
- 10. AXIAL VIBE subtraction
- 11. SAGITTAL VIBE
- 12. CORONAL VIBE